

5975 Falbourne St Unit 3,
Mississauga, ON L5R 3V8
(905) 507-2099

Product Technical document

Product:
Ergonomic 3000

Condition:
Lifting piston drifting down slowly.

Suggestion:
Lower the truck completely and remove from load. Set control lever (# 52) in middle position of travel. Using an 8mm wrench turn nut (# 45) counter-clockwise one full revolution to lower the position of the nut. When the lever (# 52) is set in the middle position of travel, the chain section of the control linkage (# 44) should have some slack. If the chain section remains tight, turn the nut (#45) counter-clockwise one additional revolution. Check for tension in the chain section. Tension should only be present when the control lever (# 52) is pulled upward to lower the forks. Once the adjustment has been made raise the truck and verify drifting has ceased.

PUMP & HANDLE ASSEMBLY ELECTRIC

