


## Stacker Battery Connection

All Lift-rite Stackers are shipped from the factory with the battery disconnected at the negative post. This is for safety purposes and prevents unanticipated actuation of the lift cylinder while the product is in transit. Before attempting to use the stacker for the first time, connect the two black wires to the negative battery post shown in the illustration. One wire is a "14 Ga." black wire lead with a ring terminal end from the battery charger. The second is a larger "4 Ga." Black wire lead with a ring terminal end coming from the frame. Connect both wires to the negative battery post and tighten the butterfly nut.



### **SAFETY SHOES**

**Always wear safety shoes when working with Manual Pallet Stackers.**

### **PROTECTIVE GLASSES**

**When assembling or dismantling a Manual Pallet Stacker, protective glasses must be worn to avoid personal injury.**

### **OPERATOR'S RESPONSIBILITY**

**While operating a Manual Pallet Stacker always wear safety equipment and operate in a responsible manner to ensure a safe work area.**